



Metallic Shimmer Bracelet

*A truly innovative bracelet design using our
Beaded Round rivoli frame links and Czech Rosette buttons.*

DESIGN BY Denise Varville (for TierraCast[®])

Instructions:

- **Preparation:** Use wire cutters to clip the shanks off of the buttons.
- **Glue the Links:** Apply a small amount (about the size of a 4 or 5mm bead) of E-6000 adhesive or two-part epoxy into the frames and set a button into each frame. Set the frames into the florist foam so that they are level and allow to dry. Alternatively – use a toothpick to apply small dabs of adhesive around the back edges of the buttons, and then set into frames. *Remember - while both E-6000 and 30-minute epoxy will “dry” quickly, they need 12-24 hours to fully cure.*
- **Assemble Bracelet:** Link the six frames together using one 5mm round jumpring between each link. Attach two jumprings at each end. (Adjust length by adding or removing jumprings.)
- **Finish:** Attach the clasp components to the jumprings at each end of the bracelet.

NOTE: *If using two-part epoxy, follow measuring and mixing instructions carefully for best results!*

What You'll Need:

TierraCast Parts:

- 1 Large Tapered Clasp
94-6067-26
- 6 Beaded Round Link
94-3119-25
- 6 Czech Rosette Button
94-6544-12
- 8-10 5mm Round Jumpring
01-0020-01

Additional Materials:

E-6000 Adhesive
~or~ a 30-minute two-part epoxy

Tools:

Wire cutters
Chain-nose and/or flat nose pliers
Florist foam for holding frames while drying (available at craft stores)

Techniques Required

Cutting wire, using adhesives, opening and closing jumprings.

Finished Size: Approx. 8"