



### What You'll Need:

#### TierraCast Parts:

- 1 Large Tapered Clasp  
94-6067-12
- 6 10mm Oasis Bead  
94-5716-12
- 10 12mm Open Scalloped Cap  
94-5590-12
- 12 SS 4mm Round Bead  
93-0110-00
- 2 2X2 Crimp Bead  
01-0030-01
- 2 3 mm Crimp Cover  
01-0032-01
- 2 5mm 16g Jumpings  
01-0020-01

#### Additional Materials:

- 1 24" length of beading wire
- 3 14mm Powder Almond pearls
- 2 18mm Ivory pearls

#### Tools:

- Crimping tool
- Wire cutters
- Chain-nose pliers

#### Techniques Required:

- Basic stringing. Using a crimping tool. Opening and closing jumpings.

# Profusely Pearl Bracelet

*This lovely pearl bracelet is so decadent our designer used a double strand of beading wire to hold its luxurious weight!*

DESIGN BY Denise Varville (for TierraCast<sup>®</sup>)

### Instructions:

- Cut the 24" strand of beading wire into two 12" pieces. Trim ends at an angle to facilitate passing the double strand back through the beads.
- Attach 1 jumping to one half of the clasp. Close jumping. Align the two 12" strands of beading wire together and use 1 crimp bead and the crimping tool to attach them to the jumping, leaving a 1 1/2" tail. Cover the crimp bead with a crimp cover.
- String one 4mm Round bead, one 10mm Oasis bead, one 4mm Round bead, one 12mm Open Scalloped Cap, one 14mm almond pearl, and a second Open Scalloped Cap, covering tail of stringing wire with the first 2 beads. Trim excess.  
\*String one 4mm Round bead, one 10mm Oasis bead, one 4mm Round bead, one 12mm Open Scalloped Cap, one 18mm ivory pearl, a second Open Scalloped Cap.\* Repeat steps \* through \* 3 more times, alternating the almond and ivory pearls. String one 4mm Round bead, the last Oasis bead, and the last 4mm Round bead.
- Use a crimp bead to attach the second jumping, passing the beading wire back through the last two beads. Trim excess. Cover crimp bead with a crimp cover. Finish the bracelet by opening the jumping and attaching the second half of the clasp. Close jumping.