



What You'll Need:

TierraCast Parts:

- 2 Bali Toggle Clasp Ring
94-6060-26
- 2 Crystal & GF 2mm earwires
90-3140-65
- 4 4mm 20ga Round jumprings
01-0024-09
- 2 6mm 19ga Round jumprings
01-0025-09
- 6 2mmx3.2mm 20ga jumprings
01-0016-09
- 10 2" 24ga headpins
01-0029-09

Additional Materials:

- 6 Swarovski 4mm bicone
crystals in Tanzanite
- 4 Swarovski 9x5mm briolette
crystals in Crystal AB
- 2 Swarovski 10.7mm Rivoli
crystals in Crystal AB
- E6000 Multi-purpose
Adhesive

Tools:

- Chain-nose pliers
- Round-nose pliers

Star of Wonder Earrings

Sparkle and shine at your holiday celebrations

DESIGN BY Tracy Gonzales (for TierraCast[®])

Instructions:

- **Create crystal dangles.** String one 4mm bicone on a headpin and form a wrapped loop. Repeat with remaining 5 bicones. String one briolette crystal on a headpin and form a wrapped bail. Repeat with remaining 3 briolettes. Attach a 2mm x 3.2mm jumpring to the 4 briolette dangles. Use E6000 adhesive to glue the 2 Rivoli crystals into the clasp rings.
- **Assemble your earrings.** Attach one 4mm round jumpring to an earwire. Before closing jumpring attach in this order: 1 bicone dangle, 1 briolette dangle, one 6mm round jumpring, 1 briolette dangle, and 1 bicone dangle. Close jumpring. To the 6mm round jumpring attach one 4mm round jumpring and 1 bicone dangle. Attach a 2mm x 3.2mm jumpring to the bottom 4mm jumpring. Add the Rivoli clasp ring to the last jumpring.