

SWAROVSKI

CREATE YOUR STYLE



May – Light Topaz

Little Drops of Sunshine

Swarovski crystals

Product Group	Article No.	Amount	Size	Color	Color Code
Fancy Stones	4470	2 pcs	10mm	Light Topaz Shimmer F	226 SHIM
Fancy Stones	4470	2 pcs	10mm	Crystal Sunshine Delite	001 L141D
Fancy Stones	4470	2 pcs	12mm	Light Topaz F	226 SHIM
Pendants	6106	4 pcs	16mm	Light Topaz	226
Beads	5328	10 pcs	4mm	Light Topaz Shimmer	226 SHIM
Beads	5328	4 pcs	6mm	Light Topaz	226
Glue in Settings	A4470JM10	4 pcs	10mm	Gold	3P1TC3
Glue in Settings	A4470JM12	2 pcs	12mm	Gold	3P1TC3

Supplies:

2—32mm Charm Keeper Hoop - TierraCast® 01-0401-25

2—Add a Bead French Ear wires TierraCast® 90-3320-00

16—4mm jump rings

12”-20g gold Artistic Wire®

Alcohol wipes

Swarovski CG500 Two Part Epoxy Glue

Instructions:

Step 1: Using alcohol wipes clean all the findings and set aside to dry.

Step 2: Using one 4470 10mm fancy stone glue into one 10mm cushion setting and set aside for 24 hours to dry. Repeat three times and set aside

Step 3: Using one 4470 12mm fancy stone glue into one 12mm cushion setting and set aside for 24 hours to dry. Repeat one time and set aside

Step 4: Cut wire into twelve 1” pieces and set aside.

Step 5: Using one wire make a simple loop at one end. Slide on one 4mm 5328 bicone bead and make a simple loop. Repeat seven more times and set aside.

Step 6: Using one wire make a simple loop at one end. Slide on one 6mm 5328 bicone bead and make a simple loop. Repeat three more times and set aside.

Step 7: Using one ear wire, slide on one 5328 4mm bicone bead and make a simple loop. Repeat once and set aside.

Step 8: Using three jump rings attach one to the 16mm 6106 pendant and then add the other two to create a chain.

Step 9: Using five jump rings attach one to the 16mm 6106 pendant and then add the other four to create a chain.

SWAROVSKI

CREATE YOUR STYLE

Step 10: Using one bead component made in Step 5, attach one 10mm 4470 component in Sunshine Delite made in Step 2. Repeat once and set aside.

Step 11: Using one bead component made in Step 5 and one made in Step 6 link together and attach the 6mm end to one 10mm 4470 component in Light Topaz Shimmer made in Step 2. Repeat once and set aside.

Step 12: Using two bead components made in Step 5 and one made in Step 6 link together and attach the 4mm end to one 12mm 4470 component in Light Topaz made in Step 2. Repeat once and set aside.

Step 13: Using the Charm Keeper Hoop, open the hoop at the top and begin to slide on components in this order:

1. Component made in Step 11
2. Component made in Step 8
3. Component made in Step 12
4. Component made in Step 9
5. Component made in Step 10

Step 14: Repeat Step 14 in the reverse order to make second earring.